

Oracle ASR Manager Installation Overview


Prerequisites

To install the ASR Manager, you will need:


- Access to My Oracle Support
- Association with appropriate Customer Support Identifier
- Current and correct contract information
- Secure internet access (https)
- Qualified Oracle systems
- Technical contact

ASR Installation Overview

Do you have an Oracle Premium Support or Warranty Contract?



ASR Manager



ASR Assets

